

PowerBook: Cause of Feedback When Attaching Microphone (11/92)

Article Created: 27 October 1992
TOPIC
FaxSender doesn't turn off the sound port after sending a fax.
DISCUSSION
When you send a document using FaxSender and then plug the microphone into the microphone jack without restarting, it will produce feedback because the sound port is still open.
Support Information Services Copyright 1992, Apple Computer, Inc.
Keywords: kpbook
This information is from the Apple Technical Information Library.
19960215 11:05:19.00
Tech Info Library Article Number: 10574