



Tech Info Library

PowerBook Drives: DOS Mounter and Disk Noise (4/94)

Article Created: 28 October 1992

Article Reviewed/Updated: 1 April 1994

TOPIC -----

My PowerBook disk drive makes strange noises when it's reading a disk. I installed DOS Mounter and everything was fine until I mounted my first DOS disk. Since then, the drive has made this strange (and loud) noise. What's wrong?

DISCUSSION -----

According to Dayna Communications tech support, the stepping routine for the drive is stored in PRAM. While the noises are normal, they are only supposed to happen when the drive is reading a DOS disk. Unfortunately, the stepping routine is supposed to return to its default for normal Macintosh operating system disks, but it doesn't.

Dayna Communications fixed this problem as of version 3.02 of DOS Mounter. DOS Mounter 3.02 or greater -- including DOS Mounter Plus -- will correctly reset the stepping routine.

To locate a vendor's address and phone number, use the vendor name as a search string.

Article Change History:

1 April 1994 - Reviewed for accuracy, updated formatting.

16 March 1993 - Revised with information about problem fix versions.

Support Information Services

Copyright 1992-94, Apple Computer, Inc.

Keywords: KPBOOK

=====

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 10893