

Macintosh Quadra 900 & 950: Unplug Before Installing NuBus Card

Article Created: 23 April 1992

Article Change History ------01/20/93 - REVISED • To include Macintosh Quadra 950 in this category.

TOPIC -----

Why must I unplug the Macintosh Quadra 900 before installing a NuBus card?

DISCUSSION -----

The Macintosh Quadra 900/950 power supply provides a +5-volt trickle voltage to one pin on the NuBus when the computer is plugged into the AC adapter. One reason for this is to allow remote startup.If the computer is not unplugged during the installation procedure, the power supply, the logic board, and/or the NuBus card may be damaged.

Consult your Macintosh Quadra 900 or Macintosh Quadra 950 Owner's Manual for the proper expansion card installation procedure.

Note

This caution does not apply to the Macintosh Quadra 700. Copyright 1992, 1993, Apple Computer, Inc.

Keywords: <None>

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 10157