



Tech Info Library

Quadra 900 & 950: Unplug Before Installing NuBus Card (11/94)

Article Created: 23 April 1992

Article Reviewed/Updated: 11 November 1994

TOPIC -----

Why must I unplug the Macintosh Quadra 900 before installing a NuBus card?

DISCUSSION -----

The Macintosh Quadra 900/950 power supply provides a +5-volt trickle voltage to one pin on the NuBus slot when the computer is connected to AC. One reason for this is to allow remote startup.

If the computer is not unplugged during the installation procedure, the power supply, the logic board, and/or the NuBus card may be damaged.

Consult your Macintosh Quadra 900 or Macintosh Quadra 950 Owner's Manual for the proper expansion card installation procedure.

Note: This caution does not apply to the Macintosh Quadra 700.

Article Change History

11 Nov 1994 - Reviewed for technical accuracy.

20 Jan 1993 - Revised to include Macintosh Quadra 950 in this category.

Support Information Services

Copyright 1992-94, Apple Computer, Inc.

Keywords: <None>

=====
This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 10156