



Tech Info Library

Performa Basics: Can't Access Quit Button (4/94)

Article Created: 6 April 1994

TOPIC -----

When running Performa Basics, I am unable to access the Quit button, or the guidance buttons. There is about an inch at the top of the program that has nothing in it.

DISCUSSION -----

You probably have 640x400 video mode turned on in your Monitor Control Panel. Open your Monitor Control Panel, and reset the monitor back to "Macintosh High Resolution" and restart. That will return your system to 640x480, and Performa Basics should run fine.

Support Information Services
Copyright 1994, Apple Computer, Inc

Keywords: <None>

=====

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 15059