



Tech Info Library

Macintosh: Setting the Serial Port Baud Rate

Article Created: 26 March 1991
Article Last Reviewed: 21 May 1992
Article Last Updated:

TOPIC -----

How do I set a device to a different baud rate on a Macintosh serial port?

DISCUSSION -----

The ability to set the baud rate for the Macintosh serial port lies with the application and/or serial port driver you're using. In most instances, the baud rate is predetermined and cannot be changed. The most notable exception is modem communication, where you can set baud from within the application. There is no default (or built-in) method for setting baud.

We would suggest contacting the driver's publisher for this type of information, because it varies from driver to driver.
Copyright 1991 Apple Computer, Inc.

Keywords: <None>

=====

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 7630