

HyperCard: Using It With Video Tape

This article last reviewed: 5 January 1988

HyperCard can be used for composing interactive videos by doing the following:

- 1. Use a high end VCR or VTR (3/4 inch tape) that allows you to accurately control tape position.
- 2. Record frame number information on a frame control track along with the video signal. If the VCR or VTR does not have this feature, HyperCard can not accurately control what is played from the video recorder.
- 3. Write your own custom HyperCard XCMD commands to control the VCR or VTR.

For further information on compatible VCR or VTR units, search under: Sony Corporation of America.

Copyright 1989 Apple Computer, Inc.

Keywords: <None>

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 1768