



Tech Info Library

AppleShare 2.0: Desktop Manager and UnMounting Cartridge Disks

This article last reviewed: 19 September 1989

TOPIC -----

I have some Videoworks/Director demos that rely on the AppleShare 2.0 Desktop Manager System file for some special file management functions. This file causes problems with removable cartridge disk systems, when ejecting one volume and mounting another.

An easy solution is to simply drag the Desktop Manager out of the System Folder. However, this means that you can't use these cartridge systems for different animation demos, unless you are willing to restart with the new cartridge in place. Do you have any other solutions?

DISCUSSION -----

Our guess is that you have a copy of the Desktop Manager in the System Folder of your startup volume. This INIT shipped with AppleShare and is intended to be used on the server but can be copied to and used with any Macintosh volume. With this INIT in place, you can't unmount any volume you mount at startup, unless you use special utilities as you mentioned above.

Removing the Desktop Manager from the System Folder of the startup volume should let you unmount volumes by dragging the volume to the Trash, as would be expected.

Copyright 1989 Apple Computer, Inc.

Keywords: <None>

=====

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 4579