



Tech Info Library

Extra Pages When Printing a Window From the Finder (2/95)

Article Created: 23 February 1995

TOPIC -----

When I print a list (View by Name) of a window from the Finder I get pages of text alternating with "blank" sheets that only have a header on each page. Why is it printing these pages with nothing but headers on them? Is there something wrong with my printer?

DISCUSSION -----

This situation occurs because the window being printed is wider than a single sheet of letter size (8 1/2 x 11) paper. The "blank" pages that only have headers on them are actually the right sides of a left and right sided two page width window. In other words, if you were to line up all of the pages side by side in two columns each, you would see that, in at least one instance, some text from the left page would "run-over" onto the right page.

To prevent this from occurring:

- Pull down the File Menu and select Page Setup. Change the orientation from Portrait to Landscape. Then print.

or

- Use the Views control panel to turn off various window elements, such as: Show size, Show kind, Show label, Show date, Show version, and Show comments. If you remove enough of these elements, you will decrease the width of the window, so that it will no longer be more than one page across.

Support Information Services
Copyright 1995, Apple Computer, Inc.

Keywords: supt,ksts,hts

=====

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 17264