

Restoration CD: Market Software Series ReadMe, Jan '95 (4/96)

Article Created: 12 September 1994	
Article Reviewed/Updated: 02 April 1996	
TOPIC	_

This file contains a listing of all the software configurations available on the CD. In addition, this file contains important information about the release of the Apple Restoration CD that supersedes information in the Apple Restoration CD User's Guide.. Refer to the on-line descriptions and those provided here when selecting a software configuration to restore on Macintosh computers.

DISCUSSION -----

Apple Restoration CD - Read Me File Market Software Series, January 1996

Restoration CD Configuration Information

For your convenience, the contents for all of the Market Software Series volumes are listed here:

Volume 10, January 1996

Description	Part Number
Education Software Summer 1995 for LC580	
7.5.1 for AELC - Student	694-0458
7.5.1 for AELC - Teacher	694-0452
7.5.1 for Early Childhood Connections	694-0450
7.5.1 for Spanish Language Connection-Student	694-0554

7.5.1 for Spanish Language Connection-Teacher 694-0543

Volume 9, January 1996

Description	Part Number
Fall 1995 Performa Software	
7.5.1 for 5200CD 7.5.1 for 6230CD 7.5.1 for 580CD	694-0652 694-0651 694-0569
Volume 8, January 1996	
Description	Part Number
Fall 1995 Performa Software	
7.5.1 for 5215CD 7.5.1 for 6200,6218 7.5.1 for 6220CD	694-0648 694-0667 694-0645
Volume 7, January 1996	
Description	Part Number
Fall 1995 Performa Software	
7.5.1 for 6205CD 7.5.1 for 6214CD 7.5.1 for 6216CD	694-0586 694-0566 694-0540
Volume 6, May 1995	
Description	Part Number
April 1995 Performa Software	
7.5 for 5200LC/75 7.5.1 for 640CD DOS Compatible	694-0408 694-0429

Volume 5, January 1995

Description	Part Number
September 1994 Performa Software	
7.5 for 6112	694-0331
October 1994 Education Software	
7.5 for AELC - Student	694-0393
7.5 for AELC - Teacher	694-0392
7.5 for Early Childhood Connections	694-0394
7.5 for Spanish Language Connection - Student	694-0396
7.5 for Spanish Language Connection - Teacher	694-0395

Volume 4, September 1994 ==========

Description	Part Number
September 1994 Performa Software	
7.5 for 637-Money Magazine Edition 7.5 for 630CD,635CD,638CD 7.5 for 630 7.5 for 636 7.1P6 for 460-Refurbished system	694-0336 694-0334 694-0348 694-0349 694-0333
April 1994 Performa Software	
7.5 for 575,577,578	694-0329
October 1993 Performa Software	
7.5 for 475-Marts/Catalog/ Consumer Electronics	694-0328

Description	Part Number

October 1993 Performa Software

7.1P6-476-Office Product Superstores 7.1P6-476-Clubs	694-0260 694-0258
April 1994 Business Software	
7.1-Quadra 605 Productivity Software	694-0290*
Education Software	
7.1-1994 Spanish Language Connection-Student 7.1-1994 Spanish Language Connection-Teacher	
July 1994 Performa Software	
7.1.2P-636 7.1.2P-636	694-0303 694-0302
Other	
7.1-Quadra 610 DOS configuration	694-0268-B

Volume 2, February 1994

Description	Part Number
Education Software	
7 1 1004 Banks Obilibrad Compactions I 0575	604 004F B
7.1-1994 Early Childhood Connections LC575	694-0245-B
7.1-1994 AELC - Student for LC575	694-0256*
7.1-1994 AELC - Teacher for LC575	694-0255*
7.1-1993 AELC - Student for LCIII	694-0235*
7.1-1993 AELC - Teacher for LCIII	694-0232*
7.1-1993 AELC - Student for LCII,LC520	694-0241*
7.1-1993 AELC - Teacher for LCII,LC520	694-0240*
7.1-1992-1993 AELC - Student for LCII,LCIII	694-0113-B
7.1-1992-1993 AELC - Teacher for LCII,LCIII	694-0112-B
7.1-1993 Q3 Educator Advantage program for	694-0239*
LCII,LCIII,Centris 610,Quadra 610	
7.0.1-1992 Back to School-Classic II,	694-0227
LCII,IIsi	
7.0.1-1992 Back to School-PowerBook	694-0226
7.1-1992 Q1 Educator Advantage program	694-0022*

Volume 1, March 1994

Description

Part Number

April 1994 Performa Software	
7.1P6 - 575,577,578	694-0275
January 1994 Performa Software	
7.1P5 - 560 - Money Magazine Edition	694-0243
October 1993 Consumer Software	
7.1 - Consumer PowerBook 145B	694-0185*
October 1993 Performa Software	
7.1P6-410-Marts/Catalog/Consumer Electronics	694-0275
7.1P6-460-Marts/Catalog/Consumer Electronics	694-0275
7.1P6-466-Marts/Catalog/Consumer Electronics	694-0275
7.1P6-475-Marts/Catalog/Consumer Electronics	694-0275
7.1P6-550-Marts/Catalog/Consumer Electronics	694-0275
7.1P3-460-Office Product Superstroes	694-0177
7.1P3-467-Clubs	694-0174
April 1993 Performa Software	
7.1P2-405-SuperStores, WordPerfect Works	694-0094
7.1P2-405,430,450-Consumer Elct.,ClarisWorks	694-0093
7.1P2-450-SuperStores, WordPerfect Works	694-0067
7.1P2-600-Consumer Electronics, ClarisWorks	694-0065
7.1P2-600CD-Consumer Electronics, ClarisWorks	694-0068
7.1P2-600-SuperStores, GreatWorks, MYOB	694-0070
7.1P2-600CD-SuperStores, GreatWorks, MYOB	694-0069
October 1992 Performa Software	
7.0.1P-200,400-GreatWorks, Quicken, T/Maker	694-0001K
7.0.1P-200,400-GreatWorks, Quicken	694-0002K
7.0.1P-200,400-ClarisWorks	694-0003K
7.0.1P-200,400-GreatWorks, MYOB	694-0004K

* Apple recommends that you install the System Update 3.0 from the CD after you install this configuration. Apple recommends that you install CD-ROM software if the computer being restored has a CD-ROM player attached.

Important Information

1. You can use the Apple Restoration CD on the Apple CD SC Plus and newer Apple CD-ROM drives. If you are not booting from the Apple Restoration CD, you also

need the appropriate CD-ROM software driver installed on your Macintosh computer.

- 2. You cannot boot from the Apple Restoration CD on Macintosh SE, SE/30, Classic, II, IIx, or IIcx computers. With these computers, start your Macintosh with a bootable hard drive and then run the Restoration CD installer program from the Other Items window that appears in the Finder.
- 3. If you're restoring software to a blank replacement hard drive in a single-drive system, the computer should boot from the Apple Restoration CD after a few seconds. If the computer has an internal hard drive capable of booting the computer, press and hold down the Shift, Option, Command, and Delete keys while starting the system. If the computer has multiple SCSI hard drives that are set up as bootable startup disks, disconnect or leave them powered off while using the Apple Restoration CD. Here are a few other notes about booting from the Apple Restoration CD:
- a. On Macintosh SE, SE/30, II, IIx, IIcx, IIci, IIfx, IIsi, and Performa 20 400, 405, and 430 computers, pressing and holding down the Shift, Option, Command, and Delete keys during startup disables the hard drive installed as SCSI device 0.
- b. On all other computers except those listed in items 2 and 3a, pressing a holding down the Shift, Option, Command, and Delete keys during startup disables the hard drive chosen with the Startup Disk control panel. If no disk was chosen with the Startup Disk control panel, the computer will either disable the hard drive installed as SCSI device 0 or the key sequence will have no effect (depending on the model of computer).
- c. In general, if you are using an Apple CD 300 player and you set the CD-R drive's SCSI device number to a higher number than a bootable hard drive, the computer should boot from the CD-ROM drive. If other devices are starting the computer, either disconnect them, set the CD-ROM drive to be the startup disk, or specify a hard drive to be the startup disk and then use the Shift-Option-Command-Delete key sequence to disable the drive. If the computer still attempts to boot from SCSI device 0, even after using the Shift-Option-Command-Delete key sequence, you can reset the startup disk to SCSI device 0 by clearing parameter RAM (pressing and holding down Option-Command-P-R keys while starting up your system). Note, however, that clearing parameter RAM also clears other user settings.

Article Change History:

02 Apr 1996 - Replace entire contents with updated information.

07 Sep 1995 - Made Minor Corrections.

08 Aug 1995 - Added Restoration CD Volume 6.

Copyright 1994-96, Apple Computer, Inc.

Keywords: supt

This information is from the Apple Technical Information Library.

19960403 07:25:13.00

Tech Info Library Article Number: 16250