



Tech Info Library

WiggleWorks: Splash Screen Displays Improperly (1/96)

Article Created: 25 January 1996

TOPIC -----

When I launch WiggleWorks on my Macintosh computer with System 7.5.2, the splash screen only displays a horizontal bar with the animation partially visible. I have tried disabling virtual memory, and selecting System 7.5.2 extensions only in the Extensions Manager, but it is still not working.

DISCUSSION -----

The problem you are encountering is caused by the Control Strip software that came with your Multiple Scan Display. This issue may occur on any Macintosh computer on which you launch WiggleWorks while the Control Strip is showing on the screen. You can see the full WiggleWorks splash screen by hiding the Control Strip before you launch the Wiggleworks application:

Step 1

Under the Apple Menu choose Control Panels.

Step 2

Double-click on the Control Strip control panel. Click the radio button next to Hide Control Strip. Close the Control Strip control panel.

Note: You can also click the Define hot key... button to set a key combination that hides and shows the Control Strip whenever you press those keys regardless of what application you are in.

Step 3

Launch WiggleWorks.

Support Information Services
Copyright 1996, Apple Computer, Inc.

Keywords: <None>

=====

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 19268