

## Introduction to Macintosh Service CD: Remove HyperCard Player

Article Created: 22 June 1993

\* RESTRICTED: Apple Internal and Support Providers Only \* Not For General Public Release

TOPIC -----

The 1.0 version and 1.1 versions of the Introduction to Macintosh Service CD DON'T work properly with HyperCard Player. If you run HyperCard Player, you'll get a "t63" error immediately upon launching the Course stacks.

For this reason, HyperCard 2.1 is on the 1.1 CD. Unfortunately, HyperCard Player is loaded onto every Macintosh when it ships. Double-clicking on the course stack launches HyperCard Player even if HyperCard 2.1 is present on the system. This article gives suggestions for working around this situation.

DISCUSSION -----

If using version 1.0 (HyperCard 2.1 isn't included on the 1.0 CD):

1) Delete HyperCard Player from the hard disk.

- 2) Obtain HyperCard 2.1 application and home stack from Apple or Claris.
- 3) Run the course using HyperCard 2.1

If using version 1.1 (HyperCard 2.1 is included on the 1.1 CD):

Delete HyperCard Player from the hard disk.
Run the course directly from the CD.

Notes:

- Copy the HyperCard application and home stack to the hard disk, or copy the entire course materials to the hard disk for faster performance.
- Launch HyperCard first and then use Command-O to open the stack once within HyperCard 2.1.
- You can also drop-launch the Course stack by making the HyperCard 2.1 application visible on the desktop and dragging the Course stack from the Service Mentor folder onto the HyperCard application icon. This launches the course stack using the HyperCard 2.1 application.
- If you wish to keep HyperCard Player, copy it to a floppy disk and store

it for later use.

• The HyperCard 2.1 application on the IMS 1.1 CD is licensed for users to copy to their hard drive.

Copyright 1993, Apple Computer, Inc.

Keywords: KCOMPAT

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 12406