



# Tech Info Library

## LAT Tool: Disconnected When Using Asante Driver (6/95)

Article Created: 17 September 1992

Article Reviewed/Updated: 1 June 1995

\* RESTRICTED: Apple Internal and Support Providers Only \*  
Not For General Public Release

TOPIC -----

I'm using Reflections to communicate via LAT from a Macintosh IIsi with an Asante Card to a VAX. I get disconnected from the VAX. Looking at the wire with a Sniffer reveals that the LAT driver is generating an "illegal format" at the time of disconnect.

Does Apple still support the LAT driver or is it Digital?

Do you have any idea what is causing the disconnect?

DISCUSSION -----

We've heard of a problem using LAT, the Asante Ethernet card, and the Asante driver together. There's no problem using the Apple driver with the Asante card. The problem also doesn't appear when using the Apple Ethernet card with the Apple driver.

First try to run with the Apple driver, and if possible, the Apple Ethernet card. If this doesn't solve your problem, you need to report the problem to Digital. They took over the source code and engineering responsibilities for PATHWORKS. They requested that all problems be reported to their Atlanta Customer Support Center.

Article Change History:

01 Jun 1995 - Reviewed for technical accuracy.

Support Information Services

Copyright 1992-95, Apple Computer, Inc.

Keywords: <None>

=====

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 10696