

## Tech Info Library

## LaserWriter Pro 810: W4 and W9 Jumpers (10/94)

Article Created: 13 October 1994

\* RESTRICTED: Apple Internal and Support Providers Only \*

Not For General Public Release

TOPIC -----

My LaserWriter Pro  $810\ \text{I/O}$  controller has two sets of jumpers labeled W4 and W9 each with pins labeled A, B, and C. What are the default positions for the jumpers?

DISCUSSION -----

On the LaserWriter Pro 810 I/O controller board there are two sets of jumpers with A, B, and C configurations. Both jumpers are used by the vendor for printer configurations that include the parallel option. Apple sells the LaserWriter Pro 810 with the Ethernet option instead of the parallel option therefore these jumpers have no effect on the Apple version of this printer.

Although this information isn't valid for the LaserWriter Pro 810 the default positions are as follows:

## Jumper W4

\_\_\_\_\_

A-B jumpered Centronics Strobe low (default position)

B-C jumpered Centronics Strobe high

Jumper W9

\_\_\_\_\_

A-B jumpered Centronics IPRIME signal enabled

B-C jumpered Centronics IPRIME signal disabled (default)

Support Information Services
Copyright 1994, Apple Computer, Inc.

Keywords: hts

-----

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 16512