



Tech Info Library

Macintosh LC: Red Switch on Logic Board Resets the PRAM (12/94)

Article Created: 7 August 1991

Article Reviewed/Updated: 05 December 1994

* RESTRICTED: Apple Internal and Support Providers Only *
Not For General Public Release

TOPIC -----

What is the red button on the Macintosh LC logic board?

DISCUSSION -----

On the original Macintosh LC, the red PRAM switch on the logic board was used for testing. This PRAM switch is no longer a part of the Macintosh LC logic board.

In the field, when a battery is changed, the PRAM may be corrupted in the process, and the logic board may not reset. If this happens, press the red PRAM switch to clear the PRAM.

Article Change History:

05 Dec 1994 - Reviewed for technical accuracy.

Support Information Services

Copyright 1991-94, Apple Computer, Inc.

Keywords: hts

=====

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 8020