

Macintosh 16-Inch Color Display: Green Vertical Line and Fix

Article Created: 14 August 1992

* RESTRICTED: Apple Internal and Support Providers Only * Not For General Public Release

TOPIC -----

When I replaced the video board (part number 661-1635) on a Macintosh 16-Inch Color Display, a green vertical line appeared on the left side of the screen outside the image area. I tried adjusting the white balance, but the line is still there.

DISCUSSION -----

A small two-position slide switch (SW1) on the video board is set incorrectly. This switch is located on the bottom of the board to the left of center. Move the position of the switch toward the center of the board, and the line will go away.

Note

You must re-adjust the monitor's cutoff and white balance after you've changed the switch position. Copyright 1992, Apple Computer, Inc.

Keywords: <None>

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 10597