



Tech Info Library

Personal LaserWriter 320: Prints Solid Black (6/94)

Article Created: 29 June 1994

* RESTRICTED: Apple Internal and Support Providers Only *
Not For General Public Release

TOPIC -----

My Personal LaserWriter 320 is printing solid black pages whenever I send it a print job. The black print extends all of the way to the edge of the page. What could be causing the problem?

DISCUSSION -----

Under some circumstances it is possible for the cleaning blade inside of the Personal LaserWriter 300 and Personal LaserWriter 320 toner to move slightly out of position which can lead to solid black pages being printed. Replacing the toner cartridge should correct the problem. If the problem continues then consult the Service Source CD for additional information.

Support Information Services
Copyright 1994, Apple Computer, Inc

Keywords: <None>

=====

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 15726