



# Tech Info Library

## QuickTake 100: LCD Panel Showing ER (6/94)

Article Created: 23 June 1994

TOPIC -----

The Quicktake 100 camera I am using is showing the letters 'ER' on the LCD panel. What does this mean?

DISCUSSION -----

This is an error state. Check that you are using the appropriate power adaptor and it is properly connected to the camera. Turn the camera off and back on. If the LCD still reads ER, have the camera serviced by an authorized Apple service provider.

Support Information Services  
Copyright 1994, Apple Computer, Inc

Keywords: <None>

=====

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 15681