



Tech Info Library

Apple Video Player: Corrupted Pref file Causes Wrong Tint (5/96)

Article Created: 3 May 1996

Article Reviewed/Updated: 8 May 1996

TOPIC -----

I am using the Apple Video Player and it worked properly for a while. However, now the input window shows everything with a pink tint. How can I get rid of the tint?

DISCUSSION -----

If the preference file gets corrupted, you get the unexpected tint. To correct this, open your Preference folder, inside your System folder, and throw away the Apple Video Player Pref file.

The next time you open the Apple Video Player a new preference file is created and Apple Video Player displays the proper tint.

Article Change History:

08 May 1996 - minor formatting change.

Copyright 1996, Apple Computer, Inc.

Keywords: <None>

=====

This information is from the Apple Technical Information Library.

19960508 15:37:40.00

Tech Info Library Article Number: 19696