

Apple MessagePad: Using Foreign Characters in Word List (5/95)

Article Created: 27 August 1993
Article Reviewed/Updated: 5 May 1995
TOPIC
I can enter words that contain non-English characters (such as "ä", "é", or " \emptyset ") into the Apple MessagePad's word list. Why do these words appear without the accent?
DISCUSSION
You can save words with non-English characters to the word list of the U.S. version of the Apple MessagePad. These words, however, are displayed without accents and the Apple MessagePad do not recognize non-English characters when you write them. We recommend that you do not enter words with non-English characters into your word list.
Article Change History: 05 May 1995 - Changed Newton to Apple MessagePad. Reformatted.
Support Information Services Copyright 1993-95, Apple Computer, Inc.
Keywords: newton
=======================================
This information is from the Apple Technical Information Library.
19960215 11:05:19.00
Tech Info Library Article Number: 13104