



Tech Info Library

Newton MessagePad: Be Careful When Pressing Reset Switch (10/93)

Article Created: 25 October 1993

TOPIC -----

What happens if I press my Newton MessagePad's reset too hard?

DISCUSSION -----

If you press the reset switch too hard, you may damage your MessagePad. Since the Newton MessagePad's reset switch produces no audible or physical response (like a 'click') when you press it, some users may expect some sort of response and press harder than normal.

You should use no more pressure on the reset switch than you use to write on the Newton's touchpad screen.

Copyright 1993, Apple Computer, Inc.

Keywords: <None>

=====

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 13783