

## Newton MessagePad: Erasing a Corrupted PCMCIA Card (11/93)

Article Created: 3 November 1993
TOPIC
This article discusses how to erase a corrupted PCMCIA card.
DISCUSSION
If you have a corrupted PCMCIA card that your Newton MessagePad that won't recognize follow these steps:
1) Remove the PCMCIA card from your MessagePad and restart the MessagePad.
2) Tap the Extras button, then tap Prefs.
3) Insert the corrupted PCMCIA card into your MessagePad. A dialog will appear which asks if you want to erase your card. Tap Yes.
Your card should now work correctly. Copyright 1993, Apple Computer, Inc.
Keywords: <none></none>
This information is from the Apple Technical Information Library.
19960215 11:05:19.00
Tech Info Library Article Number: 13866