



Tech Info Library

AppleCD 300: Differences Between Modes and Speed (5/93)

Article Created: 11 May 1993

TOPIC -----

In the AppleCD 300 User's Guide, both mode and speed are mentioned. I was under the impression that normal speed was mode 1 and double speed was mode 2.

Can you please explain the difference between mode and speed?

DISCUSSION -----

In respect to CDs, modes refer to the format of the various fields written on the compact disk (such as sync, header, data, ECC, etc.). The different modes are not a function of different drive speeds, and can be used at both single and double speed.

The AppleCD 300i and the external AppleCD 300 will play the following types of compact disks:

- CD-Audio
 - CD-ROM (modes 1 and mode 2)
 - CD-ROM XA (mode 2, form 1 and form 2)
 - CD-I (mode 1 and mode 2)
 - CD-I Ready
 - CD-I Bridge
 - Photo CD (single and multiple sessions)
- Copyright 1993, Apple Computer, Inc.

Keywords: <None>

=====

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 12079