



Tech Info Library

AppleVision 1710AV: Requires Multiple Sound Settings (12/95)

Article Created: 21 December 1995

TOPIC -----

I cannot hear any sounds from my Macintosh computer connected to my AppleVision 1710AV Display. If I use a tape player, instead of the computer as the sound source, I can hear the tape through the display. If I disconnect the external speaker connection, I can hear my computer through the internal speaker on the computer. How can I get the AppleVision 1710AV Display to play the computer sounds?

DISCUSSION -----

In the Sound & Display control panel, you must have both the AppleVision speakers AND external headphones checked in order to hear sound from the AppleVision 1710AV Display. If you only have one of these options checked, audio is not sent to the display.

Support Information Services
Copyright 1995, Apple Computer, Inc.

Keywords: <None>

=====

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 19113