

Macintosh: If It Crashes or Hangs While Saving (4/94)

Article Created: 16 August 1993 Article Reviewed/Updated: 8 April 1994

TOPIC -----

I get error messages when I try to save files to my hard drive. What's the problem?

DISCUSSION -----

If your computer crashes or hangs while saving, chances are you have a conflict with an extension or Control Panel. In this case, you should try removing non-Apple additions to your extensions folder or Control Panels as the first step towards resolving the problem.

However, crashes specifically when saving may also indicate that:

- The disk you are trying to save to is damaged
- The application you are using has been corrupted

In any of these cases, first try saving to another diskette before attempting to troubleshoot your problem.

If the Macintosh offers you a Continue button, click it and select Save As from the File menu. Save the file to a different disk, preferrably a floppy. If you do not get a Continue button, there are two ways to escape:

- 1) Try a force-quit by pressing the Command, Option, and Escape buttons on your keyboard simultaneously to quit the application you're in. You won't be able to save open documents, however.
- 2) Press the reset button on the programmer's switch on the side or back of the computer. The button is marked with a left-pointing triangle.
- If you suspect that the disk is damaged, try running Disk First Aid (on the Utilities disk included with your computer). If it cannot be repaired by the utility software, you may need service.
- If you suspect that the application you are using has become corrupted, reinstall the application from the master disks.

Article Change History: 8 April 1994 - Reviewed for technical accuracy.

Support Information Services Copyright 1993, Apple Computer, Inc.

Keywords: <None>

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 12971