

## Color OneScanner 600/27: SCSI Selector Has Wrong SCSI ID (3/96)

Article Created: 6 March 1996 Article Reviewed/Updated: 12 March 1996

TOPIC -----

The SCSI Select switch on my Apple Color OneScanner 600/27 does not select the correct SCSI ID according to the SCSI Probe software.

DISCUSSION -----

Sometimes the label on the Apple Color OneScanner 600/27 is not lined up correctly to the position of the SCSI selector switch. To correctly set the SCSI ID, turn the selector switch so the arrow is pointing up (the 12 o'clock position). Next turn the selector to the right (clockwise) and count the number of times the selector clicks. This allows you to set the proper SCSI ID.

For example, if you rotate the SCSI selector three notches, this is SCSI ID 3.

Copyright 1996, Apple Computer, Inc.

Keywords: <None>

This information is from the Apple Technical Information Library.

19960312 17:10:57.00 Tech Info Library Article Number: 19455