



Tech Info Library

Apple Color Plotter: Configuration Table

This article last reviewed: 5 April 1990

System	SW-1	
	12345678	Cable Required
Apple III	10111100	590-0037 and 590-0166
Apple IIGS		590-0037 and 590-0550
Macintosh	01111111	590-0169 *
Lisa	N/A	N/A
Apple IIc	01101100	590-0191 **
Super Serial ***	01101100	590-0037
High Speed Serial	N/A	N/A

Key

0 = off = closed

1 = on = open

* - A special plotter driver is necessary for the Macintosh.

The switch setting here is from an interface package for the Macintosh, "Plot-It" from Mesa Graphics, which works with MacPaint.

** - Using default port settings

*** - Apple II, II+, IIe require the Super Serial card

Apple III Driver Configuration:

Driver	Data Configuration Block											
	0	1	2	3	4	5	6	7	8	9	A	B
RS-232	08	22	00	00	00	00	13	11	DF	84	50	80
Printer	08	22	00	00	00							

Super Serial Card Configuration:

	1	2	3	4	5	6	7
SW1	Off	Off	Off	On	Off	On	On
SW2	On	Off	Off	On	Off	Off	Off

Jumper block should be pointing towards terminal.

Copyright 1990 Apple Computer, Inc.

Keywords: <None>

=====

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 1055