



# Tech Info Library

## LaserWriter 12/640 PS: Communication Switch Settings (8/96)

Article Created: 14 August 1996

TOPIC -----

This article contains the settings for the communication switch on the back of the LaserWriter 12/640 PS printer.

DISCUSSION -----

The following table shows the default communication settings.

Normal (in) Switch Position

=====

Begin\_Table

PORT	Network PROTOCOL	MODE	DEFAULT
LocalTalk	LocalTalk	PostScript	PostScript
Ethernet	EtherTalk	PostScript,off	PostScript
	NetWare	PostScript,PCL5, Auto,off	Auto
	TCP/IP	PostScript,PCL5, Auto,off	Auto
Parallel	TBCP	PostScript,PCL5, Auto,off	Auto
	Normal	PostScript, Off	PostScript
	Raw	PostScript, PCL5, Auto,Off	Auto

End\_Table

Reset (out) Switch Position

=====

Begin\_Table

PORT	Network PROTOCOL	MODE
LocalTalk	LocalTalk	PostScript
Ethernet	EtherTalk	PostScript
	NetWare	Auto Select
	TCP/IP	Auto Select
Parallel	Parallel	Auto Select

End\_Table

Note:

When the communication switch is set in the Reset position, a startup page is printed each time the printer is turned on and the Extended Job Status settings are removed.

Copyright 1996, Apple Computer, Inc.

Keywords: <None>

=====

This information is from the Apple Technical Information Library.

19960815 07:35:41.00

Tech Info Library Article Number: 20288