



Tech Info Library

LaserWriter 16/600 PS: How to Turn Off IPX Protocol (11/94)

Article Created: 15 November 1994

TOPIC -----

Is there a way I can turn IPX protocol off on the 16/600PS laserwriter?

DISCUSSION -----

The Apple Printer Utility that ships with the LaserWriter 16/600 PS enables you to configure the communication channels of the printer:

- 1) Verify the printer's configuration switch is in the up position (p32 of the Apple LaserWriter 16/600 PS manual).
- 2) Launch the Apple Printer Utility and select the 16/600.
- 3) Choose Communication Configuration from the menu
- 4) Choose "Up Switch Position (Custom)"
- 5) Set the Netware mode to off.

When you quit the Apple Printer Utility, you'll have the option to send this change to the printer: click send.

Support Information Services
Copyright 1994, Apple Computer, Inc

Keywords: <None>

=====

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 16755