



Tech Info Library

LaserWriter 16/600 PS: Disabling Energy Saver W/ PS Code (1/96)

Article Created: 22 December 1994

Article Reviewed/Updated: 26 January 1996

TOPIC -----

Is there a way to disable the Energy Saver feature on the LaserWriter 16/600 PS printer using PostScript?

DISCUSSION -----

The code for disabling the energy saver mode on the LaserWriter 16/600 PS is shown below. Paste the code into a text document and then use the LaserWriter Utility or Apple Printer Utility to download it to the printer.

Caution:

If you choose to use the PostScript code provided in this article, you assume all risks involved in making these changes. PostScript code, if not entered correctly, can place the LaserWriter into a condition requiring service.

```
%=====
% Begin PostScript code
%
(%Engine%) << /Password 0 /TimeToStandby 0 >> setdevparams
%
% End PostScript code
%=====
```

In order to re-enable the energy saving mode use the built-in power saving options menus built into the LaserWriter Utility and Apple Printer Utility.

Article Change History:

26 Jan 1996 - Added PostScript caution message.

Support Information Services

Copyright 1994, Apple Computer, Inc

Keywords: <None>

=====

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 16937