



Tech Info Library

LaserWriter 16/600 PS: Setting the Paper Tray (3/95)

Article Created: 9 March 1995

TOPIC -----

I am having multiple problems with LaserWriter 16/600 with 500 sheet optional trays. They do not pull from the 500 sheet tray all the time. For example, in Microsoft Word printing using the keys Command-P pulls paper from 500 sheet tray. Using the print option in the tool bar, pulls paper from multi-purpose tray. Using the File menu and choosing Print, pulls paper from the 500 sheet feeder. I have had similar problems in both Microsoft Works and Microsoft Excel. The 500 sheet feeder is installed and preferred in the Chooser.

DISCUSSION -----

This is an application problem where the vendor is using different print records when doing a "Print One" as opposed to using the pull-down Print menu.

To correct this problem, follow these steps:

Step 1

Create a SimpleText file and enter the following lines of PostScript code.

Note:

PostScript is case sensitive. The PostScript code must be entered exactly as it shown.

```
%=====
% Begin PostScript Code
%
serverdict begin 0 exitserver
statusdict begin 2 setdefaultpapertray end
%
% end PostScript Code
%=====
```

The following values for the number before "setdefaultpapertray" above:

0	250 Sheet Cassette
1	Multi-purpose tray

- 2 500 Sheet Cassette
- 3 Envelope tray

Step 2

Save the file and quit SimpleText.

Step 3

Launch Apple LaserWriter Utility, under the Utilities menu, choose Download PostScript File.

Support Information Services
Copyright 1995, Apple Computer, Inc.

Keywords: <None>

=====

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 17340