

LaserWriter II: Removing the Protective Cover

This article last reviewed: 22 March 1988

The LaserWriter II's installation instructions refer to a "protective cover" that must be removed. This is the styrofoam that is taped across the opening of the controller board slot. This styrofoam is to keep debris out of the controller board area during shipment.

The antistatic insulator taped to the bottom panel of the LaserWriter II "engine" should NOT be removed. It will cause no problems when left in place.

Copyright 1989 Apple Computer, Inc.

Keywords: <None>

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 2701