



Tech Info Library

How to Connect to Network Printers (7/96)

Article Created: 8 October 1991

Article Reviewed/Updated: 01 July 1996

TOPIC -----

This article covers these topics:

- Basic preparations for networking and background printing
- Connecting to network printers
- Selecting background printing
- System 7.x hints and help
- Where to get more information

DISCUSSION -----

Before You Connect

To connect to network printers, you need the following items installed in the System Folder:

- LaserWriter or LaserWriter 8 (With LaserWriter 8 Print Driver you also need the PPD files from the installer disk.)
- LaserWriter Prep (under System 6.0.x only)

To use background printing, PrintMonitor also must be installed in the System Folder (under System 7.x, in the Extensions folder within the System Folder). If you need to install any of these items, use your set of system disks to do so. Under System 7.x, use the copy of the Installer on the Printing disk.

Connecting to Network Printers

Follow these steps to connect to network printers:

- 1) From the Apple menu, select Chooser. The Chooser window appears. AppleTalk must be set to Active in the lower-right part of the Chooser window.

- 2) In the upper-left part of the Chooser window, click the icon of the type of printer you want (this must be a network printer, for example LaserWriter).
- 3) Scroll the list of AppleTalk Zones to find the one you want.
- 4) Click the name of the AppleTalk Zone to select it. A list of printers and print spoolers in that zone appears in the right-hand window.
- 5) Click on the name of a printer or print spooler to select it. If you use LaserWriter 8, you must click the "Setup..." button and setup the printer. You may either use Auto Setup, or chose More Choices to select a specific PPD.
- 6) From the File menu, select Close, or click on the close box in the upper-left corner of the Chooser window.

Selecting Background Printing

With PrintMonitor, you can print on a LaserWriter while continuing to work with other programs (this is called background printing). Follow these steps to select background printing:

- 1) From the Apple menu, select Chooser. The Chooser window appears.
- 2) Click the LaserWriter icon in the upper-left part of the Chooser window.
- 3) Click the On radio button in the Background Printing section (below the list of LaserWriters).
- 4) From the File menu, select Close, or click on the close box in the upper-left corner of the Chooser window.

System 7.x Hints and Help

- To move between sections of the Chooser, press the Tab key.
- To move to an item quickly within any section of the Chooser, type one or more characters that begin the name of the desired item.

Where to Get More Information

- Macintosh Networking Reference by Apple Computer, Inc. (030-3936-A)
- Macintosh Reference (System 6.0.x) by Apple Computer, Inc. (030-4015-A)
- Macintosh Reference (System 7) by Apple Computer, Inc. (030-3934-A)

This article is one of many available through the Apple Fax center. For a complete list of available fax documents, search the Tech Info Library for Apple Fax Document Index or call the Apple Fax line at 1-800-505-0171 and select document number 20000 (Apple Fax - Document Index - Product Support Literature).

The Apple Fax center is available free of charge 24 hours a day, 7 days a week.

Article Change History:

- 01 Jul 1996 - Added Fax Doc Word
- 28 Sep 1994 - Reviewed for technical accuracy.
- 12 Jul 1994 - Reviewed for technical accuracy.

Support Information Services

Copyright 1991-96, Apple Computer, Inc.

Keywords: sys7,kfax

=====

This information is from the Apple Technical Information Library.

19960701 12:44:03.00

Tech Info Library Article Number: 9388