



# Tech Info Library

## LaserWriter 8.x: Cover Page Printed With Every Document (10/94)

Article Created: 28 October 1994

TOPIC -----

Whenever I print a document an extra page is printed with information that resembles the following:

User	John Doe
Application	Print Monitor
Document	README- System 7
Date	Sat. Oct 22 94
Time	
Printer	LaserWriter 16/600 PS"

Why is this page printed and how can I turn it off?

DISCUSSION -----

The LaserWriter 8 driver allows you to specify whether or not to print a cover page with each print job.

Modifying the Settings

- 
- 1) Select 'print'
  - 2) Press the 'options' button  
The top option determines whether there should be a cover page, and whether it should print before or after the print job.
  - 3) Select 'none' and the cover page no longer prints

The buttons are sticky so they remember the settings from the previous print job.

Support Information Services  
Copyright 1994, Apple Computer, Inc

Keywords: <None>

=====

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 16633