



Tech Info Library

LaserWriter Driver 8.x: LW Icon Isn't in Chooser (11/96)

Article Created: 21 November 1996

TOPIC -----

I am installing my LaserWriter printer and the instructions say to select LaserWriter 8 in the chooser. I have installed the software multiple times, but there is still nothing in the chooser that reads LaserWriter 8.

DISCUSSION -----

Check the listing of icons in the Chooser for a printer labeled LaserWriter GX. If you see this printer active, you have QuickDraw GX installed and active. When QuickDraw GX is active, non-GX printer drivers, such as the LaserWriter 8 are hidden, and only the QuickDraw drivers are available. You can select and use the LaserWriter GX icon instead of the LaserWriter 8 driver if you want. For more information about Quickdraw GX consult the documentation that came with your system software, and the manual that came with your printer.

Copyright 1996, Apple Computer, Inc.

Keywords: <None>

=====

This information is from the Apple Technical Information Library.

19961122 07:37:55.00

Tech Info Library Article Number: 20664