



Tech Info Library

Portable StyleWriter: Undocumented Self Tests (10/93)

Article Created: 1 October 1993

TOPIC -----

This article describes additional self test information that is not documented in the Owner's manual.

DISCUSSION -----

Make sure paper is loaded into the printer first. All of the tests are continuous. To stop the tests, turn off the printer.

- 1: Power on the printer. After the beep let up on the power button, press the "PITCH" button and hold it until you hear another beep. Then, let up on the "PITCH" button. The printer will print a sample of the 11 built-in fonts for the CANON BJ-10e.
- 2: Power on the printer. After the beep, let up the power button. Press the "LF/FF" button and hold it down until you hear another beep. Then let up on the "LF/FF" button. The printer will print a "barber pole" test print.
- 3: Power on the printer while holding down the "ON LINE" and "LF/FF" buttons. After the first beep, let up on the power button. After the second beep let go of the "ON LINE" and "LF/FF" buttons. The printer will print rows of "H"s.

Copyright 1993, Apple Computer, Inc

Keywords: <None>

=====

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 13581