



Tech Info Library

Portable StyleWriter: Out of Paper Error (6/96)

Article Created: 17 June 1996

TOPIC -----

I have a Portable StyleWriter and when I choose Print, a dialogue box appears telling me that the printer is out of paper, but the printer has paper loaded. What am I doing wrong?

DISCUSSION -----

In the Print dialogue box there is an option for Feed: Automatic or Manual. If Manual is selected, the printer will prompt you to insert a sheet of paper. If Automatic is selected, you will not see this dialogue box.

Copyright 1996, Apple Computer, Inc.

Keywords: supt

=====

This information is from the Apple Technical Information Library.

19960618 16:20:42.00

Tech Info Library Article Number: 20049