



Tech Info Library

StyleWriter II: Controls and Status Lights (4/95)

Article Created: 6 January 1993

Article Reviewed/Updated: 7 April 1995

TOPIC -----

The StyleWriter II has a power button, two paper thickness levers, and two status lights. This article discussed the StyleWriter II's controls and status lights.

DISCUSSION -----

Power Button

=====

The Power button is located on the top center of the printer. You can turn the printer on or off by pressing down on the Power button. To print a test page, press and hold down the Power button for several seconds until the test page starts to print. Release the Power button when the test page begins to print.

Paper Thickness Levers

=====

The paper thickness levers are located on the right side of the printer. One lever is on the outside of the printer, next to the paper tray. This lever controls the width of the space through which the paper enters the printer. The other lever is colored blue and is located inside the printer on the top right side of the print head mechanism. This lever controls the distance the print head mechanism is from the paper. The levers have two positions:

- Normal (for up to 100 normal sheets of paper)
- Envelope (for thicker paper or up to 15 envelopes)

The normal position has a document icon next to it (a piece of paper with the corner folded over) and the envelope position has an envelope icon next to it.

Status Lights

=====

The two status lights are located on the upper center front panel.

- The Power light is the rectangular light located over the Apple logo.
- The Error light is the small round light just to the left of the Power light.

Status Light Indications

The green Power light comes on when power is applied to the printer; it blinks when the printer is printing.

The yellow Error light comes on to indicate one or more of the following situations:

- The printer is out of paper
- There is a paper jam
- There is a carriage jam inside the printer

Article Change History:

07 Apr 1995 - Made minor technical updates; removed LED chart.

17 Feb 1995 - Added LED condition chart.

Copyright 1992-95, Apple Computer, Inc.

Keywords: kalley

=====
This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 11176