



Tech Info Library

StyleWriter: How to Avoid Paper Jams

Article Created: 25 July 1991

Article Last Reviewed:

Article Last Updated:

TOPIC -----

Have there been any reported paper-jamming problems with the StyleWriter printers?

DISCUSSION -----

We haven't received any reports of paper-jamming problems with the StyleWriter printers.

The StyleWriter has a detachable cut-sheet feeder that easily connects to the printer. When the sheet feeder is connected properly, the product performs flawlessly. When attaching the sheet feeder, ensure that the sheet feeder is locked in place and that the paper support is installed; it's also important to press the release button on the sheet feeder to snap the paper panel forward for proper positioning. The sheet feeder holds up to 50 sheets of 20-pound paper and automatically feeds the paper while printing.

The StyleWriter can be used without the sheet feeder with front or rear manual feed. The front and rear manual-feed options simplify the printing of single-sheet paper, envelopes, labels, and transparencies.

Paper-Feed Features

- Detachable cut-sheet feeder accurately feeds up to 50 sheets automatically.
- Rear manual-feed slot is ideal for printing materials like envelopes, labels, transparencies, and heavy paper.
- Front manual-feed slot provides easy access for standard paper.

Copyright 1991 Apple Computer, Inc.

Keywords: <None>

=====

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 7934