



Tech Info Library

StyleWriter II: No Background Printing With WordPerfect (2/95)

Article Created: 3 February 1995

TOPIC -----

When I print from WordPerfect v3.0 to my StyleWriter II, it continues to spools my document until I run out of disk space. How can I correct this?

DISCUSSION -----

This problem occurs with Word Perfect v3.0 and any serial printer such as the StyleWriter II, Personal LaserWriter 300, and LaserWriter Select 300. To correct this problem permanently, contact WordPerfect for an upgrade.

Deleting Spooled Documents
=====

- 1) Open the System Folder
- 2) Throw the Print Monitor Documents folder into the Trash
- 3) Restart

Temporary Workaround
=====

- 1) Open the Chooser
- 2) Turn off Background Printing

Do not try printing the same document. If you do, the same thing will happen again. Sometimes you can copy the document and paste the information into a new document, then print the new document.

To locate a vendor's address and phone numbers, use the vendor name as the search string.

Support Information Services
Copyright 1995, Apple Computer, Inc

Keywords: <None>

=====

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 17125