



Tech Info Library

LaserWriter Pro Energy Star: Setting Engine Sleep Values 7/93

Article Created: 9 July 1993

TOPIC -----

I'm using the LaserWriter Pro Energy Star software that sets the LaserWriter Pros to sleep after a certain period of inactivity.

After downloading the PostScript commands, the PostScript log reads "Engine sleep timeout changed to x hours", where x is .5, 1, 2, or 4 hours.

What PostScript commands can I use to set/change or read the value of "Engine sleep timeout"?

DISCUSSION -----

The PostScript commands in the LaserWriter Pro Energy Star files are proprietary commands which we ourselves were unable to obtain from engineering. Thus, the sleep time files for setting the sleep timeout to .5, 1, 2, or 4 hours are the only ones available.

Copyright 1993, Apple Computer, Inc.

Keywords: <None>

=====

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 12559