



Tech Info Library

Lisa 7/7 (version 3.0): UNABLE TO PRINT message

When your Lisa informs you it's having difficulties printing your document, check everything suggested by both the dialog message and the manual, and then try the following.

1. Open Preferences and click on Connect devices. Select each of the connections (e.g., Serial A Connector), and set each to Nothing.
2. Re-select each of the connections in Connect Devices, and select what you physically have connected to the Lisa at that connection.
3. Click on Select Defaults in Preferences and make your printer the default printer.
4. Open your document and choose Format for Printer from the File/Print menu. Click on the "New Printer..." button, then select a printer different from what is currently selected (a new default printer). Finally, select Format for Printer and choose the printer you wish to print the document on.

Apple Technical Communications

Keywords: <None>

=====

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 900