



Tech Info Library

Personal LaserWriter NTR: Communication Switch Settings (4/94)

Article Created: 5 April 1994

TOPIC -----

This article describes the communication switch settings on the Personal LaserWriter NTR printer.

DISCUSSION -----

WARNING: If you choose a non-LocalTalk setting for the LocalTalk (8-pin) port while the printer is connected to an AppleTalk network, you can do permanent damage to devices on the network! Settings 1, 4, 5, and 6, (and possibly 9, since you can customize 9) are non-LocalTalk settings for the 8-pin port. Before you choose one of these settings, disconnect any LocalTalk connector box connected to the printer.

If you have a non-Macintosh computer that requires special settings to work with the Personal LaserWriter NTR, you can choose a different group of settings. You use the ten-position push-button switch on the back of the printer to choose a group of setting.

If you need to change the setting, check the following table for the switch position that corresponds to the setting you need. If you need to additional settings and have access to a Macintosh computer, you can program position 9 using the LaserWriter Utility software.

Settings -----

Switch Number	Port Name	Connect Type	Baud Rate	Parity	Data Bits	Stop Bits	Flow Cntrl	Protocol	Mode
0	Din-8	LocalTalk	-	-	-	-	-	-	PS
	RS-232	Serial	9600	None	8	1	XON/XOFF	Normal	PS
	Parallel	Centronic	-	-	-	-	-	Normal	PS
1	Din-8	Serial	9600	None	7	1	XON/XOFF	-	PS
	RS-232	Serial	9600	None	7	1	XON/XOFF	Normal	PS
	Parallel	Centronic	-	-	-	-	-	Normal	PS

2	Din-8	LocalTalk	-	-	-	-	-	-	HP
	RS-232	Serial	9600	None	8	1	XON/XOFF	Normal	HP
	Parallel	Centronic	-	-	-	-	-	Normal	HP
3	Din-8	LocalTalk	-	-	-	-	-	-	HP
	RS-232	Serial	9600	None	8	1	DTR	Normal	HP
	Parallel	Centronic	-	-	-	-	-	Normal	HP
4	Din-8	Serial	1200	None	7	1	XON/XOFF	-	PS
	RS-232	Serial	1200	None	7	1	XON/XOFF	Normal	PS
	Parallel	Centronic	-	-	-	-	-	Normal	PS
5	Din-8	Serial	9600	None	8	1	XON/XOFF	Normal	PS
	RS-232	Serial	9600	None	8	1	XON/XOFF	Normal	PS
	Parallel	Centronic	-	-	-	-	-	Normal	PS
6	Din-8	Serial	9600	None	8	1	XON/XOFF	Binary	PS
	RS-232	Serial	9600	None	8	1	XON/XOFF	Binary	PS
	Parallel	Centronic	-	-	-	-	-	Binary	PS
7	Din-8	LocalTalk	-	-	-	-	-	-	PS
	RS-232	Serial	9600	None	8	1	XON/XOFF	Normal	PS
	Parallel	Centronic	-	-	-	-	-	Normal	PS
8	Din-8	LocalTalk	-	-	-	-	-	-	PS
	RS-232	Serial	9600	None	8	1	XON/XOFF	Normal	PS
	Parallel	Centronic	-	-	-	-	-	Normal	HP
9	Din-8	LocalTalk	-	-	-	-	-	-	PS
	RS-232	Serial	9600	None	8	1	XON/XOFF	Normal	PS
	Parallel	Centronic	-	-	-	-	-	Normal	PS

PS - PostScript

HP - HP PCL 4

* - Nonprinting input: This is used when a device-such as an automatic sheet feeder-is connected to the serial port and receives special commands from a computer connected through another of the printer's ports.

Available Settings

The following table briefly describes the communication settings and lists the options available for each.

Setting	Description	Options
Baud Rate	The speed of transmission between the computer and printer.	300, 600, 1200, 1800, 2400, 3600, 4800, 7200, 9600, 19200,

Parity	The method used to compare transmitted and received data to check for errors.	None, odd, even, mark, space
Data Bits	The number of bits used to represent each character.	7, 8
Stop Bits	The number of bits used to indicate the end of a character.	1, 2
Flow Control	The method used to prevent transmitted data from exceeding the rate at which the receiving end can accept it.	XON/XOFF, DTR ETX/ACK
Protocol	The digital format in which the data is presented.	Normal, Raw, Binary
Mode	The communication standard used to transmit data	Postscript, HP Printer Command Language 4, and Nonprinting Input (not intended for a computer connection)

Support Information Services
Copyright 1994, Apple Computer, Inc

Keywords: <None>

=====

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 15070