



Tech Info Library

Macintosh II and Macintosh IIX: Guided Tour Disks (1/95)

Article Created: 10 August 1987

Article Reviewed/Updated: 2 February 1995

TOPIC -----

The following is an explanation why the Mac II Guided Tour disk will not launch in some situations.

DISCUSSION -----

On a 1 megabyte Macintosh II, the Guided Tour disk will not launch if the Monitors control panel setting has been changed to:

1. Colors
2. 16 shades/levels
3. or both

The additional RAM required by Color QuickDraw for data manipulation causes the memory available for the Guided Tour to decrease below the required 960K. The shipping default settings are Black & White and 2 colors.

On a Macintosh II with 2MB of RAM, even with the RAM Cache set to 1536K and Monitor control panel set to 256 Colors, the Guided Tour always boots. RAM Cache settings are ignored by the Guided Tour system file.

Article Change History:

2 Feb 1995 - Reviewed for technical accuracy.

Support Information Services

Copyright 1987-1995 Apple Computer, Inc.

Keywords: <None>

=====
This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 2289