



# Tech Info Library

## Multiple Scan 17 Display: Replacing CN513 Connectors (11/94)

Article Created: 4 November 1994

\* RESTRICTED: Apple Internal and Support Providers Only \*  
Not For General Public Release

TOPIC -----

I am replacing the main deflection board and forgot where the two connectors from CN513 go. The connector has four wires; two red, and two white. These wires pair up to the two connectors; black and white. Where do the connectors go?

DISCUSSION -----

The white connector goes to the large part of the yoke and the black connector goes to the small part of the yoke.

Support Information Services  
Copyright 1994, Apple Computer, Inc

Keywords: <None>

=====  
This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 16699