



Tech Info Library

Parallel/Centronics Card Pin-Out

This article last reviewed: 2 December 1988

These two cards although different in name, are virtually identical apart from those differences outlined below.

PIN OUTS (same for both cards)

20 Pin Header	Signal Name
1.....	Ground - Pin 1 and 20 must be used.
2.....	ACK (Handshake)
8.....	Strobe out
10.....	Bit 0 (LSB)
11.....	Bit 1
12.....	Bit 2
13.....	Bit 3
14.....	Bit 4
15.....	Bit 5
16.....	Bit 6
17.....	Bit 7 (MSB)
20.....	Ground - Pin 1 and 20 must be used

NOTE: The differences between the two cards are as follows.

CENTRONICS:

The Centronics card is supplied with the PROM P9 (341-0019) installed and does NOT add a linefeed after carriage return. The Jumper block is pre-configured for negative STROBE and positive acknowledge (ACK) signals.

PARALLEL:

The Parallel card is supplied with the PROM P1 (341-0005) installed and does add a linefeed after carriage return. With this card you must wire the jumper block yourself. For further information please refer to page 6 of the card's manual.

Copyright 1988 Apple Computer, Inc.

Keywords: HTS,CNFG

=====

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 1418