



Tech Info Library

LaserWriter Pro 600/630: Fuser Temperature (11/94)

Article Created: 14 December 1993

Article Reviewed/Updated: 15 November 1994

* RESTRICTED: Apple Internal and Support Providers Only *
Not For General Public Release

TOPIC -----

What is the fuser temperature for the LaserWriter Pro 600 and 630?

DISCUSSION -----

The fuser temperatures for the LaserWriter Pro 600/630 are as follows:

	Normal Temp. Control	Initial Warm-Up Control		
	Non-envelope & Envelope	Non-envelope		Envelope
		0-5 min.	5-15 min.	0-15 min.
Standby	172 C (342 F)	187 C (369 F)	187 C (369 F)	187 C (369 F)
Printing	183 C (361 F)	203 C (397 F)	193 C (379 F)	198 C (388 F)

The initial warm-up control is initiated for the first 15 minutes whenever the initial temperature detected by the thermistor is 50 degrees C (122 degrees F) or less to improve fusing.

Article Change History:
15 Nov 1994 - Reviewed for technical accuracy.

Support Information Services
Copyright 1993-94, Apple Computer, Inc.

Keywords: <None>

=====

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 14229