

## LaserWriter/LaserWriter Plus: External Pinouts (7/94)

Article Created: 29 May 1985 Article Reviewed/Updated: 12 July 1994

TOPIC -----

What are the external signals associated with the DB-25 and DB-9 connectors on the LaserWriter and LaserWriter Plus?

```
DISCUSSION -----
```

Here are the pinouts and signal names for the LaserWriter and LaserWriter Plus.

DB-25 Connector Signal Name

1	 Frame Ground
2	 Transmit Data (Tx)
3	 Receive Data (Rx)
4	 Request to Send (RTS)
7	 Signal Ground
20	 Data Terminal Ready (Tx)

NOTE: The other signals are not used.

DB-9

Connector Signal Name

1	Chassis Ground
3	Signal Ground
4	Transmit Data (Dx+)
5	Transmit Data (Tx-)
7	Data Set Ready (DSR)
8	Receive Data (Rx+)
9	Receive Data (Rx-)

NOTE: RTS and DTR are only present for the convenience of the computer that the LaserWriter is attached to. You should use Xon/Xoff for flow control.

Article Change History: 12 Jul 1994 - Revised formatting, reviewed for technical accuracy.

Support Information Services

Copyright 1985-94, Apple Computer, Inc.

Keywords: <None>

\_\_\_\_\_

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 965