



Tech Info Library

LaserWriter IINTX: Pinouts For SIMM Connectors

This article last reviewed: 16 November 1988

Here are the pin-out signals for the SIMM connectors in a LaserWriter IINTX:

1 - GND	17 - A3	33 - Q4	49 - S6
2 - NC	18 - GND	34 - W4	50 - D7
3 - VDD	19 - GND	35 - A8	51 - Q7
4 - VDD	20 - D2	36 - S4	52 - W7
5 - CASN	21 - Q2	37 - A9	53 - S7
6 - D0	22 - W2	38 - A10	54 - Q8
7 - Q0	23 - A4	39 - A11	55 - RASN
8 - W0	24 - S2	40 - D5	56 - NC
9 - A0	25 - A5	41 - Q5	57 - CAS8
10 - S0	26 - D3	42 - W5	58 - NC
11 - A1	27 - Q3	43 - WRN	59 - D8
12 - D1	28 - W3	44 - S5	60 - NC
13 - Q1	29 - A6	45 - GND	61 - VDD
14 - W1	30 - S3	46 - D6	62 - VDD
15 - A2	31 - A7	47 - Q6	63 - NC
16 - S1	32 - D4	48 - W6	64 - GND

Copyright 1988 Apple Computer, Inc.

Keywords: <None>

=====

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 3453