



Tech Info Library

LaserWriter: Form feeds and blank pages

This article last reviewed: 7 June 1985

In Diablo 630 Emulation mode, the LaserWriter prints a page under two conditions: (1) when it reaches the end of a page, or (2) when it receives a form feed. The LaserWriter cannot detect the end of a document; it simply assumes that the document has come to an end when data stops arriving.

If the last page of a document isn't full and doesn't end with a form feed, the printer doesn't print it immediately; instead, it waits for a printer timeout, which occurs (1) as soon as the next document arrives, or (2) after 30 seconds, if no document arrives before that. You can avoid this delay by being careful to include a form feed at the end of your document's last page.

During printing there is a step called data preparation. In this step, the Laserwriter determines how many pages it takes to print the document. There is a possibility that one character, even a carriage return, will force the generation of a blank page at the end of the document. With MacWrite documents, the Laserwriter prints this last page first.

<None>

Keywords: <None>

=====

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 980